

# Le Perch Outdoors

## OWNERS MANUAL



Model LP1122  
Ultralight Portable Tree Seat  
(patent pending)

### **PLEASE READ AND SAVE THESE IMPORTANT INSTRUCTIONS**

- !** This seat is not intended for above ground level use. Do not place any higher than with feet touching the ground during use.
- !** This seat is not intended for weights in excess of 280 pounds.
- !** This seat is designed for use on healthy trees or solid posts in the size range of 8" to 18" in diameter. Failure to secure the seat onto an appropriate tree or post could result in serious personal injury.
- !** Folding and unfolding of hinged parts may produce pinch points if not handled properly.
- !** Improper setting of the seat leg into the tree or post surface may result in slippage of the leg collapsing the seat and causing the user to fall.

### **SETUP AND USE**

Your Le Perch Outdoors ultralight portable tree seat comes fully assembled and ready for immediate use and is available in either flat black (LP1122-B) or camo (LP112-C). The endless ratchet strap used to secure the seat to a tree or post may be adjusted for use as a shoulder strap for easy transport of your folded seat. Or if you are backpacking, you may find it convenient to transport your folded seat in your backpack.

The foam seat is a closed cell neoprene foam that is resistant to water making it practical for use in damp weather conditions. The seat rotates a full 360 degrees and because its pivot point is off center front-to-back, it offers two positions: closer to or further away from the tree or post to maximize your seating comfort.

When not in use as a seat, your seat can serve as a handy shelf around the campsite. The foam seat pad is fastened with Velcro<sup>®</sup> and may readily be removed to provide a more rigid surface when used as a shelf.

Your Le Perch Outdoors ultralight portable tree seat may be quickly installed on your favorite tree (post) using the following recommended steps:



Figure 1



Figure 2

1. Fully open the ratchet by lifting the handle and depressing the spring-loaded locking tabs to release the ratchet spindle to rotate while pulling the strap from the spindle.
2. Unfold the seat and place vertically against the tree or post as shown in Figure 1 making sure the tree grip is aligned parallel with the tree (post). The tree grip should be placed at the desired height above the ground that is consistent with a comfortable seat height for the user. (Typically, this height is 20" to 26" for an adult.)
3. While keeping the tree grip in place against the tree (post), wrap the free end of the strap around the tree or post and insert it into the slot of the ratchet spindle. Pull the free end of the strap until the strap is snug against the tree (post). Depress the locking tabs to release the ratchet handle and begin to ratchet the strap tight against the tree (post) making sure the tree grip feet fully engage the tree (post) at the desired height. [*CAUTION: Tighten the strap as tight as possible to avoid slippage when weight is placed on the seat.*]
4. Raise the seat until the seat support is slightly above parallel with the ground and place the seat leg firmly against the tree (post) according to Figure 2.
5. With the seat leg firmly in position, press down on the seat to set the seat leg into the tree (post) surface. [*Caution: The seat leg must grip the tree (post) by slightly indenting the surface to avoid slippage when weight is placed on the seat.*]
6. Carefully place your weight on the seat to be certain it is properly set then sit back and enjoy the outdoors.
7. Your Le Perch seat may remain in the sitting position when not in use or you may lift the seat slightly to release the seat leg and allow it to unfold against the tree (post). This is the recommended position if the seat is to remain on the tree unoccupied for an extended length of time.

#### **Seat transport:**

Fully fold the seat leg and tree grip onto the seat support engaging the rubber bumpers and secure with the attached Velcro<sup>®</sup> strap. Adjust the length of the tree strap by winding more or less of the strap on the ratchet spindle until it comfortably fits over your shoulder. Your Le Perch portable tree seat is now ready to be transported comfortably as a 'shoulder bag'. Alternatively, slip your securely folded Le Perch portable tree seat into your favorite back pack for handsfree carry.

#### **Warranty**

Le Perch Outdoors, LLC warrants as limited herein to the original purchaser of retail that each new ultralight portable tree seat, shall be free of defects in material and workmanship for a period of one (1) year from date of original purchase.

In the event of malfunction or failure of your Le Perch Outdoors ultralight portable tree seat, simply send the complete unit, postage paid along with PROOF OF PURCHASE, within the warranty period of one (1) year, to: Le Perch Outdoors, LLC. Le Perch Outdoors, LLC reserves the right to inspect the claimed defective part(s) to determine if the defect or malfunction complaint is covered by this warranty. Le Perch Outdoors, LLC shall within sixty (60) days of receipt of the product, at its option, repair and/or replace the defective part(s) free of charge. This warranty shall only cover defects arising from normal usage. Le Perch Outdoors, LLC assumes no responsibility whatsoever if the tree seat should fail during the warranty period by reason of

- Misuse, negligence, physical damage or accidents.
- Repair by an unauthorized party during the warranty period.

Le Perch Outdoors, LLC makes no further warranties or representations, expressed or implied except those contained herein. Le Perch Outdoors, LLC shall in no event be liable for direct, indirect, special or consequential damages

[www.leperchoutdoors.com](http://www.leperchoutdoors.com)