

OWNERS MANUAL



Model LPR010 Canopy

PLEASE READ AND SAVE THESE IMPORTANT INSTRUCTIONS

- ⚠ The Canopy is designed for use on healthy trees or solid posts in the size range of 8" to 18" in diameter. Failure to secure the Canopy onto an appropriate tree or post could result in serious personal injury.**
- ⚠ Failure to properly secure the hook & loop slope cord will result in collapse of the canopy, impacting anyone beneath it.**
- ⚠ Use in windy conditions (in excess of 20 mph) could result in collapse of the canopy causing possible injury to anyone beneath it.**
- ⚠ This canopy is intended for use within arm's reach of the ground. Attempts to install at greater height may result in serious injury from a fall.**

SPECIFICATIONS

The waterproof Le Perch Outdoors Canopy (LPR010) is available in either Ottertex[®] urethane coated ripstop polyester fabric (LPR010) in dark brown, hunter green, bright orange, or bright orange with optional "Shadow-Leaf Breakup". It is a nominal 2 pound 3'x3' canopy that mounts to any tree or post (8"-20" diameter) using a 1"x6' ratchet strap. The pitch of the canopy is achieved by raising the excess fabric at the tree and securing with the attached hook & loop slope cord. The canopy readily disassembles by detaching it from the tree grip rods and disengaging the incorporated shock corded fiberglass rails; folding into quarters and then rolling into a bundle. The rolled canopy combined with the tree grip reduces to a nominal 5" dia x22" bundle secured with included hook & loop strap.

SETUP AND USE

Your Le Perch Outdoors canopy is assembled by unrolling and unfolding the canvas on a flat surface and engaging the incorporated shock corded fiberglass rails at the metal sleeves and the front elbows. Tuck the front fiberglass rail and elbows into the front pouch flap. Firmly secure the tree grip using the attached 1" x 5' ratchet strap at the desired height on the tree or post. Engage the fiberglass rods into the metal sleeves. Press the canopy's rear elbows onto the

extended fiberglass tree grip rods. Pivot the canopy upwards toward the tree (or post) such that it rests above the fiberglass rods of the tree grip. While holding the canopy in this position take the hook & loop slope cord and secure it around the tree (or post) approximately 8" above the ratchet strap. Slowly release the canopy to a horizontal position. Gravity creates the tension in the canopy that holds it in position and forms the pitch with the excess material at the tree (or post).

It may be necessary to change the distance between the slope cord and the ratchet strap along with the tightness of the hook & loop slope cord on the tree (or post) for the canopy to remain in the horizontal position with pitch of the excess canvas fully developed. **CAUTION: If the slope cord is not properly secured the canopy will collapse toward the base of the tree (or post). When properly installed a slight upward curvature of the extended tree grip fiberglass rods may be noted.** The canopy may remain in this open position for extended periods of time or by reducing the tension in the slope strap it may pivot down against the tree to reduce the risk of being damaged while remaining in place when not in use.

Parts

1 each; 3'x3' waterproof fabric with incorporated 3/8" shock corded fiberglass frame
1 each; tree grip with 1"x6' ratchet strap
1 each; 0.8"x5' hook & loop slope cord
1 each; 1/2"x15" Velcro^R bundle strap

Warranty

Le Perch Outdoors, LLC warrants as limited herein to the original purchaser of retail that each new Canopy, shall be free of defects in material and workmanship for a period of one (1) year from date of original purchase.

In the event of malfunction or failure of your Le Perch Outdoors Canopy, simply send the complete unit, postage paid along with PROOF OF PURCHASE, within the warranty period of one (1) year, to: Le Perch Outdoors, LLC, 8406 Lylwood Ct., Chesterfield, VA 23838. Le Perch Outdoors, LLC reserves the right to inspect the claimed defective part(s) to determine if the defect or malfunction complaint is covered by this warranty. Le Perch Outdoors, LLC shall within sixty (60) days of receipt of the product, at its option, repair and/or replace the defective part(s) free of charge. This warranty shall only cover defects arising from normal usage. Le Perch Outdoors, LLC assumes no responsibility whatsoever if the Canopy should fail during the warranty period by reason of

- Misuse, negligence, physical damage or accidents.
- Repair by an unauthorized party during the warranty period.

Le Perch Outdoors, LLC makes no further warranties or representations, expressed or implied except those contained herein. Le Perch Outdoors, LLC shall in no event be liable for direct, indirect, special or consequential damages